

Riser Kit Installation

Easy to install and retrofit kit for access holes.

The riser kit comes complete with the required amount of risers and riser screws, dome cover with integrated handles and cover screws, bitumen sealant, and a 24"/20' riser adapter. A safety screen can also be added for extra security and peace of mind.

To find out more: email sales@polylok.eu, call us today or visit polylok.eu



Clear enough space around your access hole to accommodate the adapter ring. Clean the surface of the concrete. Add the bitumen sealant around the base of the adapter ring. then fix the ring to the concrete with anchor bolts (not supplied).



Add your riser to the adapter ring making sure to add the gasket around the base of the riser first. Then use the hex head screws (supplied) to screw the riser into place.



Add more risers if needed using the gaskets and hex head screws.



Add a safety screen (optional extra) to prevent accidental tank entry by children or pets/small animals.



Add your cover when at finished grade. The cover can be screwed into place using the cover screws supplied. (A pedestrian dome cover is supplied with integrated handles.)



Backfill evenly around the risers up to the cover and the project is complete. Polylok risers can be added if more height is needed.

You can also see the 5 step riser kit installation video under resources on the polylok.eu home page (page 2) for easy installation instructions. Alternatively, there are many useful installation videos online by satisfied polylok customers to view too. Simply search for 'Polylok Riser kit installation' on google videos.

We are always happy to offer advice: email sales@polylok.eu, call us today or visit polylok.eu